

Description

This industry standard has always been popular on power houses where metal tape measures can be forbidden.

When you get familiar with using a folding rule it's hard to go back to a tape measure for layout work.

These folding rules are the best for panel boards, in tight electrical rooms over branch circuit panels and for reflecting layout to walls and ceilings.

Their wood construction also makes them safer around live gear.

This is the Model 966, it is not an engineers or brick layers rule. it has no slide rule or depth gauge.

It has simple 1/16" graduations, left and right read.